



5.

- 1) Attach PR-155 MIG welder [S] as shown.
- 2) Attach PR-2 welder [R] to the upper shelf as shown. Use spacer [8] between welder and a shelf.
- 3) Attach cable holders [O] to the PR-2 welder.





























6.

- 1) Attach hangers [N] to the back panel as shown.
- 2) Attach MIG bottle support plate [I] to the bottom tray as shown.
- 3) Put your gas bottle on the back of the cart and secure with chains [P]




PRO SPOT Companion Cart Assembly Instructions

- | | | | |
|----------------|-----------------------|-----------|---------------|
| A - P6-05 | J - PSC-13 | 1 - S-05 | 10 - N-03 |
| B - PSC-03 | K - PSC-12 | 2 - S-43 | 11 - W-03 |
| C - PSC-02 | L - P10-05A | 3 - P-05 | 12 - PSC-18Y |
| D - PSC-01 | M - P10-35 | 4 - SR-07 | 13 - PR-155DY |
| E - PSC-05 | N - P10-38 | 5 - W-24 | |
| F - PSC-06 | O - P6-18 | 6 - W-20 | |
| G - PSC-04 | P - M-88 | 7 - N-06 | |
| H - PR-2000-13 | R - PR-2 Welder | 8 - M-82 | |
| I - PSC-07 | S - PR-155 MIG Welder | 9 - S-44 | |

<p>PSC-01 <i>Right Side Panel</i></p>  <p>1 pc.</p>	<p>PSC-02 <i>Left Side Panel</i></p>  <p>1 pc.</p>	<p>PSC-03 <i>Rear Panel</i></p>  <p>1 pc.</p>	<p>PSC-04 <i>Pull Handle</i></p>  <p>1 pc.</p>
<p>PSC-05 <i>Lower PR-155 Shelf</i></p>  <p>1 pc.</p>	<p>PSC-06 <i>Upper PR-2 Shelf</i></p>  <p>1 pc.</p>	<p>P6-05 <i>Bottom Tray</i></p>  <p>1 pc.</p>	
<p>P6-18 <i>Cable Holder</i></p>  <p>2 pc.</p>	<p>PSC-07 <i>Mig Bottle Support Plate</i></p>  <p>1 pc.</p>	<p>PR-2000-13 <i>Wheel Plate</i></p>  <p>2 pc.</p>	<p>PSC-12 <i>Wheel</i></p>  <p>2 pc.</p>
<p>P10-38 <i>Hanger</i></p>  <p>2 pc.</p>	<p>P10-35 <i>End Cap</i></p>  <p>2 pc.</p>	<p>PSC-13 <i>Axle</i></p>  <p>1 pc.</p>	<p>M-88 <i>Chain for Mig Bottle</i></p>  <p>2 @ 19" ea.</p>
<p>S-43 <i>M6x10</i></p>  <p>42 pc.</p>	<p>S-44 <i>M6x16</i></p>  <p>4 pc.</p>	<p>S-05 <i>M6x30</i></p>  <p>8 pc.</p>	<p>N-03 <i>M6 Nut</i></p>  <p>8 pc.</p>
<p>W-24 <i>1/2" Washer</i></p>  <p>2 pc.</p>	<p>M-82 <i>Spacer</i></p>  <p>4 pc.</p>	<p>P-05 <i>U-Bolt</i></p>  <p>2 pc.</p>	<p>SR-07 <i>SnapRing</i></p>  <p>2 pc.</p>
		<p>N-06 <i>1/4-20 Nut</i></p>  <p>4 pc.</p>	<p>W-03 <i>M6 Lock Washer</i></p>  <p>4 pc.</p>
		<p>W-20 <i>LockWasher</i></p>  <p>12 pc.</p>	


1.

- 1) Attach wheel plates [H] to the bottom tray [A] using included screws [2].
- 2) Secure axle [J] using U-Bolts [3]. Make sure that axle is centered.
- 3) Attach wheels [K] as shown below using snap rings [4].
Put washer [5] between bottom tray [A] and wheel [K].
- 4) Attach casters [L] using included screws [2].
- 5) Insert end caps [M].




3.

- 1) Attach lower shelf [E] to the back and side panels as shown.
- 2) Attach pull handle [G] to the lower shelf [E] using screws [1].



2.

- 1) Attach back panel [B] using screws [2] as shown.
- 2) Attach left [C] and right [D] panels using screws [2] as shown.



4.

- 1) Attach upper shelf [F] to the back panel and pull handle as shown.

